

MODELING NOTES FOR ASHRAE STANDARD 140

=====
INTRODUCTION
=====

This document shall include supplemental information about the ASHRAE Standard 140 tests performed. One S140outNotes document shall be provided for each set of tests (e.g., one for the building thermal and fabric load tests of Section 7.2; one for the space cooling equipment analytical verification tests of Section 9.2; etc.) The types of information listed below shall be provided in this document, each in a separate section:

- a. Software information
- b. Alternative modeling methods
- c. Equivalent modeling methods
- d. Nonspecified inputs
- e. Omitted test cases and results
- f. Changes made to source code for the purpose of running the tests, where such changes are not available in publicly released versions of the software
- g. Anomalous results.

Notes in this document shall be limited to the topics shown above. Notes must be factual and objective and shall only refer to the software being tested. Notes shall not refer to any other software program.

INFORMATIVE NOTE: Text at the start of each section describes the content of the section for the reader and provides instructions for supplying the content. Sample notes are provided in a separate document (S140outNotes_Examples.TXT).

=====
A. SOFTWARE INFORMATION
=====

CONTENT: This section shall include reference information for the software - the vendor, name, and version of the software, plus operating system and computer hardware requirements.

INSTRUCTIONS: Information for items 1 through 7 below shall be provided. Information for Item 8 shall be permitted but is not required.

1. SOFTWARE VENDOR: Thermal Energy System Specialists, LLC and Transsolar Energietechnik GmbH
2. SOFTWARE NAME: TRNSYS
3. SOFTWARE VERSION (unique software version identifier): 18.06.0002
4. OPERATING SYSTEM REQUIREMENTS: Windows 10, Windows 11
5. APPROX HARD DISK SPACE REQUIRED FOR INSTALLATION: Maximum = 415 MB; Minimum (to run input files) = 51 MB
6. MINIMUM RAM REQUIRED FOR SOFTWARE OPERATION: 128 MB
7. MINIMUM DISPLAY MONITOR REQUIREMENTS: VGA with 600x800 resolution and 256 colors
8. OTHER HARDWARE OR SOFTWARE-RELATED REQUIREMENTS: None

INFORMATIVE NOTE: Item 8 can be used to supply additional relevant information.

=====

B. REPORT BLOCK FOR ALTERNATIVE MODELING METHODS

=====

CONTENT: If the software being tested provides alternative modeling methods or algorithms for performing the tests, this section shall describe modeling methods used for the tests.

INSTRUCTIONS: If alternative modeling methods are applicable, a separate note for each alternative modeling method or algorithm situation shall be provided. The standard format shown below and a separate number and title for each note shall be applied. If alternative modeling methods are not applicable, specify "NONE" in place of the information below.

NOTE 1 - Building Geometry

1.1 Describe the Effect Being Simulated:

1.2 Optional Settings or Modeling Capabilities:

- Manual
- Mixed
- 3D Data

1.2.1 Manual:

Physical Meaning: The manual geometry mode allows the user to manually enter the wall surface area. Thus, the user has to provide the necessary orientation information for the software's radiation processor.

1.2.2 Mixed:

Physical Meaning: The mixed geometry mode allows 3D data and manually entered wall surface area data.

1.2.3 3D Data

Physical Meaning: The 3D Data geometry mode requires the use of the plugin to create the building envelope. The advantage of using the 3D Data Geometry mode is that it allows the use of the automatic radiation processing for the different surface orientations of the building. It also allows for the ability to use the detailed beam, diffuse, and longwave radiation mode. Furthermore, the detailed radiation modes allow other capabilities including the implementation of emissivity in the longwave radiation mode.

1.3 Setting or Capability Used:

- Manual

NOTE 2 - Wall Conduction

2.1 Describe the Effect Being Simulated:

Wall conduction

2.2 Optional Settings or Modeling Capabilities:

"Massive layer"

"Massless layer"

2.2.1 Massive layer:

Physical Meaning: takes into account the thermal capacity of the material

2.2.2 Massless layer:

Physical Meaning: uses a resistive only conduction calculation for this layer.

2.3 Setting or Capability Used:

Massless layer

NOTE 3 - Surface Convective Heat Transfer Coefficients

3.1 Describe the Effect Being Simulated:

Convective Heat Transfer Coefficients

3.2 Optional Settings or Modeling Capabilities:

Userdefined
Internal Calculation

3.2.1 Userdefined

Physical Meaning: As a default, the software package has userdefined constant convective heat transfer coefficients for interior surfaces, 11 kJ / h m² K, and for exterior surfaces, 64 kJ / h m² K. The software also allows the user to make this value an input into the Type56 Multizone building component, so a transient value may be used from another component or an equation with a wind velocity correlation. For values less than 0.001 kJ / h m² K, the documentation exclaims the following from the software documentation, "05-MultizoneBuilding.pdf": "For wall types with a known boundary temperature, the convective heat transfer coefficient can be set to a very small value (less than 0.001 kJ/h m² K) to force the surface temperature of the wall to be equal to the boundary temperature. The use of a very small value can be confusing but was kept for backwards compatibility reasons."

3.2.2 Internal Calculation

Physical Meaning: It is possible to choose internal calculation for any surface within a zone if desired for the interior surface. The user has to select whether the wall is a floor, a ceiling, or vertical to fit the appropriate heat transfer mechanism.

3.3 Setting or Capability Used:

A userdefined value was implemented for the interior and exterior convective heat transfer coefficients. The radiative part of the heat transfer coefficient is 4.63 W/m² K. However, as stated in section 5.4.1.7.2, the combined heat transfer coefficient of the heat transfer roof surface is set to 20 W/m² K (72 kJ/h m² K), and for the other surfaces' interior and exterior were set to a small allowable non-zero number.

NOTE 4 - Ground Coupling

4.1 Describe the Effect Being Simulated:
Ground Coupling

4.2 Optional Settings or Modeling Capabilities:
Userdefined Constant Temperature
Input Temperature

4.2.1 Userdefined Constant Temperature

The user can define a constant value for the back side temperature for the back side of the floor temperature (ground temperature).

4.2.2 Input Temperature

Physical Meaning: An input temperature may also be implemented for the back side temperature of the floor (ground temperature). As an input to the TRNSYS Building component, another component's ground temperature output can provide the input to this ground temperature. There is a simple ground temperature component in the TRNSYS standard library, but that still will not provide enough accuracy with for the building to earth heat transfer. There is also a slab on grade component in TRNSYS that will calculate the ground temperature based on the work that was completed for the IEA Annex 34/43 as well as additional ground coupling components in the add-on TESS Component Libraries.

4.3 Setting or Capability Used:

Input temperature: Since the floor is decoupled thermally from the ground a constant temperature equal to the given deep ground temperature of 10 °C is used.

(The ambient temperature output of the weather reader was implemented as the input to the back side of the floor.)

NOTE 5 - Temperature Control

5.1 Describe the Effect Being Simulated:
Temperature Control

5.2 Optional Settings or Modeling Capabilities:
Temperature Level Control
Energy Rate Control

5.2.1 Temperature Level Control

Physical Meaning: In temperature level control in the TRNSYS Building model calculates the air temperature based on the energy balance of the zone (infiltration, gains, ventilation, etc.) just as a real, physical building would perform.

A thermostat component would "watch" the zone temperature (the zone temperature output from the TRNSYS Building Component would be the monitoring temperature input to the thermostat component), and turn on or off the zone's conditioning equipment to send conditioned air to the zone.

Just as a real conditioned zone performs, the conditioning equipment would be on when the temperature is within the deadband of the setpoint temperature of the thermostat.

5.2.2 Energy Rate Control

Physical Meaning: The TRNSYS Building model can operate in energy rate control where the building model calculates and outputs the amount of sensible energy (removed for cooling the zone and added for heating) to maintain a user-defined setpoint temperature. Since the cases in the standard require implementation of part load ratios, it was determined to operate the TRNSYS building in energy rate control.

5.3 Setting or Capability Used: Energy Rate Control

NOTE 6 - Setpoint Temperature

6.1 Describe the Effect Being Simulated: Setpoint Temperature

6.2 Optional Settings or Modeling Capabilities: Setpoint Temperature as a constant Setpoint Temperature as an input

6.2.1 Setpoint Temperature as a constant

Physical Meaning: The TRNSYS building model allows the user to define a constant setpoint temperature in energy rate control in the TRNSYS building application, TRNBuild.

6.2.2 Setpoint Temperature as an input

Physical Meaning: The TRNSYS building model allows the user to define the setpoint temperature as an input to the building so, a setpoint schedule component could be used to supply the input. For the cases HE220 and HE230 which required a setback, a schedule component was used to provide the setpoint input to the building component.

6.3 Setting or Capability Used:

Setpoint temperature as a constant in cases for section 5.4.2;
setpoint temperature as an input for the cases in section 5.4.3.2
and 5.4.3.3.

NOTE 8 - Simulation time step

8.1 Describe the Effect Being Simulated: Simulation time step

8.2 Optional Settings or Modeling Capabilities: userdefined constant value

8.2.1 userdefined constant value

Physical Meaning: Simulation time step

8.3 Setting or Capability Used:

The simulation time step is 15 minutes: Time step = 0.25

NOTE 9 - Simulation convergence tolerances

9.1 Describe the Effect Being Simulated:

Convergence tolerances

9.2 Optional Settings or Modeling Capabilities:

Absolute Tolerances

Relative Tolerances

9.2.1 Absolute tolerances

Physical Meaning: Specifying an absolute tolerance indicates that TRNSYS should not converge until all connected outputs are changing by a value of TolA and all integration outputs are changing by a value of TolD

9.2.1 Relative tolerances

Physical Meaning: Specifying a relative tolerance indicates that TRNSYS should not move on to the next time step until all connected outputs are changing by less than (100 TolA) percent of their absolute value and all integrated outputs are changing by (100 TolD) percent of their absolute value.

9.3 Setting or Capability Used:

Relative Tolerances: 0.001 0.001

NOTE 10 - Integration

10.1 Describe the Effect Being Simulated:

Integration

10.2 Optional Settings or Modeling Capabilities:

Type24 Integrator Component

Type46 "Printegrator" Component

10.2.1 Type24 Integrator Component

Physical Meaning: Since TRNSYS simulates dynamically with inputs and outputs (i.e. mass flow rates, energy rates, etc.), and integrator component is required to quantify the rate over a specified time value. The TRNSYS Type24 Integrator Component integrates any specified output over any period of simulation time (i.e. a timestep, 1 hour, 1 month, or 1 year). The integrated values such as the load are necessary for the other values the simulation (such as part load ratio); therefore, the Type24 integrator component was used in the simulations.

10.2.2 Type 46 "Printegrator" Component

Physical Meaning: The TRNSYS Type46 "Printegrator" Component not only integrates any components' output over a user defined timeperiod, but it also "prints" the integrated value to a text output file.

10.3 Setting or Capability Used:
Type 46 "Printegrator" Component

=====

C. REPORT BLOCK FOR EQUIVALENT MODELING METHODS

=====

CONTENT: This section shall describe equivalent modeling methods used to perform the tests. When the software does not model an effect exactly as stated in the standard or does not permit the input values required, equivalent modeling methods shall be permitted to perform the test.

INSTRUCTIONS: If equivalent modeling methods are applied, a separate note for each instance of equivalent modeling shall be provided. The standard format shown below and a separate number and title for each note shall be applied. If equivalent modeling methods are not applicable, specify "NONE" in place of the information below.

NOTE 1 - Preconditioning of Zone

1.1 Describe the Effect Being Simulated:
Preconditioning of Zone

1.2 Section(s) of the Standard where Relevant Inputs are Specified:
5.1.6

1.3 Equivalent Input(s) Used:
Zone initial values were set to the temperature of 20 degrees C and a percent relative humidity of 50%.

1.4 Physical, Mathematical or Logical Justification of the Equivalent Input(s) - provide supporting calculations, if relevant:
For each zone in the TRNSYS building model, the user can provide initial condition values for the zone temperature and percent relative humidity, so the initial zone temperature was set to the thermostat setpoint from the standard, and the initial zone percent relative humidity was left at the default of 50%.

NOTE 2 - Part Load Ratio

2.1 Describe the Effect Being Simulated:
Part Load Operation

2.2 Section(s) of the Standard where Relevant Inputs are Specified:
5.4.1.10.4

2.3 Equivalent Input(s) Used:
TRNSYS Equation Block to Calculate Part Load Operation

2.4 Physical, Mathematical or Logical Justification of the Equivalent Input(s) - provide supporting calculations, if relevant:

Since the intention of this standard is to use part load ratio to depict efficiency degradation, the TRNSYS building model operates in energy rate control to output the sensible energy demand of the zone. The capacity of the heating device is constant. The quotient of the instantaneous sensible energy demand from the zone and the capacity of the heating device in an equation block was used to obtain the part load ratio (PLR). Using the correlations from section 5.4.1.10.4 in the TRNSYS equation block, the fuel consumption and input energy were calculated.

NOTE 3 - Indoor Fan Power

3.1 Describe the Effect Being Simulated:

Indoor Fan Power

3.2 Section(s) of the Standard where Relevant Inputs are Specified:

5.4.2.6

3.3 Equivalent Input(s) Used:

Part load ratio as a control signal for variable speed fan

3.4 Physical, Mathematical or Logical Justification of the Equivalent Input(s) - provide supporting calculations, if relevant:

The TRNSYS Type147 variable speed fan was used to cycle and deliver air to the zone. The fan cycled based on the part load ratio (PLR) variable that was calculated in the TRNSYS equation (see previous note). The rated fan power was specified as a parameter for Type147 variable speed fan, so when the PLR variable from the TRNSYS equation block supplied the control signal, it cycled appropriately. For section 5.4.2.5 Case HE150, the fan was set to have a constant control signal, so the fan remained on during the course of the simulation. Implementing the fan with this method also added the necessary sensible fan energy to the zone. The output of the fan, fan power, was integrated to quantify the amount of power that it consumed throughout the simulation.

NOTE 4 - Weather Data Reader

4.1 Describe the Effect Being Simulated:

Weather Data

4.2 Section(s) of the Standard where Relevant Inputs are Specified:

5.4

4.3 Equivalent Input(s) Used:

The TRNSYS Type9 Data Reader

4.4 Physical, Mathematical or Logical Justification of the Equivalent Input(s) - provide supporting calculations, if relevant:

The TRNSYS software package contains a standard weather data reader component that is compatible with the many different weather file formats (TMY, TMY2, TMY3, EPW, IWEC, and CWEC). However, the TRNSYS standard data reader component, Type9 was used to read the data into the simulation. For the cases in section 5.4.3 when the radiation values were non-zero, the radiation processing component was implemented to process the radiation for the different surfaces of the building.

=====
D. REPORT BLOCK FOR USE OF NON-SPECIFIED INPUTS
=====

CONTENT: This section shall describe nonspecified inputs used to perform the tests. Use of nonspecified inputs shall be permitted only for the following specified sections relating to the following topics:

- * Alternative constant exterior surface coefficients in Sections 5.2.1.9.3, 5.2.3.1.4.3, 5.2.3.3.2, and 5.3.1.8
- * Alternative constant interior surface coefficients in Sections 5.2.1.10.3, 5.2.3.1.4.4, 5.2.3.2.2, and 5.3.1.9
- * Alternative constant interior solar distribution fractions in Sections 5.2.1.12, 5.2.2.1.2.2, 5.2.2.1.6.2, 5.2.2.1.7.2, 5.2.2.2.7.4, 5.2.3.9.3, 5.2.3.10.2, and 5.2.3.12.2
- * Air density given at specific altitudes for the space-cooling and space- heating equipment cases in Sections 5.3.1.4.3, 5.3.3.4.3, and 5.4.1.4.3.

INSTRUCTIONS: If nonspecified inputs are applied, a separate note for each use of nonspecified inputs shall be provided. The standard format shown below and a separate number and title for each note shall be applied. If nonspecified inputs are not applied, specify "NONE" in place of the information below.

NONE

=====
E. REPORT BLOCK FOR OMITTED TEST CASES AND RESULTS
=====

CONTENT: This section shall describe test cases that were omitted and/or individual results of test cases that were omitted along with the reason for the omission.

INSTRUCTIONS: If test cases were omitted, a separate note to describe each type of omission shall be provided. The standard format shown below and a separate number and title for each note shall be applied. If there are no omitted test cases, specify "NONE" in place of the information below.

NONE

=====
F. REPORT BLOCK FOR CHANGES TO SOURCE CODE FOR THE PURPOSE OF RUNNING THE TESTS, WHERE SUCH CHANGES ARE NOT AVAILABLE IN PUBLICLY RELEASED VERSIONS OF THE SOFTWARE
=====

=====
CONTENT: This section shall describe changes to software source code made to allow the software to run a test, where such changes are not available in a publicly released version of the software.

INFORMATIVE NOTE: This section addresses special situations where a change to source code is necessary to activate a feature or to permit inputs needed for a test when these features are not available in the publicly released version of the software.

INSTRUCTIONS: If changes to the source code for the purpose of running a test are applied, separate notes to describe each source code modification shall be provided. The standard format shown below and a separate number and title for each note shall be applied. If changes to source code are not applied, specify "NONE" in place of the information below.

NONE

=====
G. REPORT BLOCK FOR ANOMALOUS RESULTS
=====

CONTENT: Describing anomalous results shall be permitted but is not required. If anomalous test results are described, this section shall be used.

INSTRUCTIONS: If anomalous test results are described, each type of anomalous result shall be described in a separate note. The standard format shown below and a separate number and title for each note item shall be applied. If anomalous results are not discussed, it shall be permitted to specify "NONE" in place of the information below.

NONE